




Brightwater
FLY ANGLER

Brightwater Ultimate Cap Light Instructions



FEATURES

- Ultra bright 5 white LED bulbs.
- Easy hat clip for hands free use.
- Lightweight
- Push ON/OFF switch.
- 2 CR2032 batteries included.



BATTERY REPLACEMENT

- Slide the battery lid out.
- Replace with 2 new CR2032 size batteries.
- Be sure batteries are installed in correct position according to mark on light body.
- Close battery cover and slide back into place.



IMPORTANT

- Do not mix old and new batteries.
- Do not look directly into LED light.
- Use only under adult supervision.

Brightwater Fly Angler
www.brightwaterflyangler.com
mark@brightwaterflyangler.com

Brightwater Fly Angler – P.O. Box 202 - Wasco, Illinois 60183
630-532-0367 630-587-9837 fax
www.brightwaterflyangler.com
mark@brightwaterflyangler.com